

IDC6 SOFTWARE

SETUP MANUAL

IDC6

TEXA

Rev.

ENGLISH.....5

SUMMARY


1 REVISION OF THE MANUAL.....	5
2 INTRODUCTION.....	6
3 SYSTEM REQUIREMENTS.....	7
3.1 Requirements that are Common to All the Supported Operating Systems	7
4 BLUETOOTH RESOURCES.....	9
5 PRELIMINARY OPERATIONS.....	10
6 CUSTOMER WITH ACTIVE IDC5 LICENCE AND ACTIVE TEXPACK SUBSCRIPTION.....	11
7 NEW CUSTOMER.....	15

1 REVISION OF THE MANUAL

This document is the setup manual for the software: IDC6

Document Review Number: 04

Date of Issue: 28/07/2025

INFORMATION	<i>Read this manual before using the product. Read the documents carefully whenever the General Risk symbol is shown.</i>
	

2 INTRODUCTION

Dear Customer,

We would like to thank you for choosing a TEXA product for your workshop.

We are certain that you will get the greatest satisfaction from it and receive a great deal of help in your work.

Please read through the instructions in this manual carefully and keep it for future reference.

Reading and understanding the following manual will help you to avoid damage or personal injury caused by improper use of the product to which it refers.

TEXA S.p.A reserves the right to make any changes deemed necessary to improve the manual for any technical or marketing requirement; the company may do so at any time without prior notice.

This product is intended for use by technicians specialised in the automotive field only. Reading and understanding the information in this manual cannot replace adequate specialised training in this field.

The sole purpose of the manual is to illustrate the operation of the product sold. It is not intended to offer technical training of any kind and technicians will therefore carry out any interventions under their own responsibility and will be accountable for any damage or personal injury caused by negligence, carelessness, or inexperience, regardless of the fact that a TEXA S.p.A. tool has been used based on the information within this manual.

Any additions to this manual, useful in describing the new versions of the program and new functions associated to it, may be sent to you through our TEXA technical bulletin service.

This manual should be considered an integral part of the product to which it refers. In the case it is resold the original buyer is therefore required to forward the manual to the new owner.

Reproduction, whole or in part, of this manual in any form whatsoever without written authorization from the producer is strictly forbidden.

The original manual was written in Italian, every other language is a translation of the original manual.

© **copyright and database rights2025** The material contained in this publication is protected by copyright and database rights. All rights are reserved by law and under international conventions.

3 SYSTEM REQUIREMENTS

Below you will find a list of system requirements for installing the software on a PC.

IDC6 is compatible with the following Microsoft operating systems:

- **Windows 10** (22H2 19045.xxx or higher)
- **Windows 11**

NOTICE

The following operating systems are not supported:

- **Windows RT;**
- **Windows 10 S;**
- **Windows 10 LTSC 2015;**
- **Windows 11 SE;**
- **Windows Insider Preview builds.**

NOTICE

This software is not compatible with devices based on an ARM processor and equipped with a Windows operating system.

INFORMATION

We recommend checking for updated information by visiting the website:<https://www.texa.com/system/>

3.1 Requirements that are Common to All the Supported Operating Systems

Requirement	Minimum	Recommended
Space on hard disk	10 GB*	15 GB*
RAM	8 GB	8 GB
System	64 bit	64 bit
Screen resolution	1024x768 pixel	--
USB ports (type A)	Yes 1	Yes 2
Internet connection	Yes	Yes
Bluetooth 4 or higher	No	Yes
WiFi	No	Yes

NOTICE

The values marked by "*" are indicative and can vary based on the environments and software versions.

We recommend checking for updated information by visiting the website:www.texa.com

Be sure to have sufficient available space on the hard disk before proceeding with the installation.

NOTICE

We recommend installing the updates from Windows Update before proceeding with the Setup.

INFORMATION

The request for space on the hard disk refers to a single diagnostic environment for its first installation.

The recommended space takes into account the possibility to update the software to higher versions.

The Internet connection is necessary (and mandatory) in order to access the on-line services, perform updates, etc.

In order to optimise the use and reduce the risk of possible compatibility problems, we recommend that this software be installed on a PC that is dedicated exclusively to workshop use.

INFORMATION

In order for the software to work properly, additional components must be installed on the PC.

The application that manages the software download and installation will carry out a quick scan of the PC, checking which additional components must be installed.

The number of additional components that must be installed varies depending on the operating system, the service pack, other previously installed environments/versions, etc.

The installation of some additional components may require you to restart the system.

The installation automatically resumes each time the system is restarted.

The time required and the steps involved in the installation depend on the number and on the type of additional components that must be installed.

4 BLUETOOTH RESOURCES

The software provides special automatic configuration functions for products equipped with Bluetooth technology.

To use these functions, you must install the software on a PC equipped with Bluetooth peripheral devices.

The software supports the following drivers:

- *Microsoft™*

INFORMATION

If the drivers used are not supported by the software, you will not be able to use the automatic configuration procedures.

As an alternative, use the Bluetooth manual configuration functions provided by your operating system.

We recommend not installing Bluetooth peripheral devices (USB flash drives) on PCs with a built-in Bluetooth system.

We recommend checking the Bluetooth system configurations and, if necessary, refer to qualified personnel for further information.

5 PRELIMINARY OPERATIONS

INFORMATION

You must have system administrator rights in order to install the software correctly.

Below are the preliminary operations to carry out before starting the installation of the software:

- *close all active applications;*
- *disconnect any USB hardware keys / parallels if the installation is being carried out on a PC;*
- *deactivate any protection system (antivirus software, firewall, spyware removal tools);*
- *disconnect any diagnostic device connected via USB to the platform on which you wish to install the software;*
- *for a proper use of the software, we recommend disabling the PC's standby mode from **Control Panel - Power Saving Options.**;*
- *keep the device on which you are installing the software powered by the mains throughout the installation.*

NOTICE

Do not turn your PC off for any reason during the installation unless specifically requested by the software.

In order to complete the installation correctly, do not interrupt or cancel the processes that are launched.

INFORMATION

Do not connect the HASP key (USB hardware key that acts as a protection device against software piracy) before you are requested to by the software.

6 CUSTOMER WITH ACTIVE IDC5 LICENCE AND ACTIVE TEXPACK SUBSCRIPTION

The installation procedure below is reserved for customers who have:

- An active IDC5 licence
- An active TEXPACK subscription

INFORMATION

Use of the software is regulated by specific licence contracts displayed during the activation and that must be read and accepted by the Customer. Likewise, the licence contract must be accepted by the Customer at each update by the licensor. The licence contract can be consulted at any time in the specific software section.


Proceed as follows:

1. Launch the software you have.

2. Press: 

The list of updates available is displayed.

3. Select the desired update.




4. Press: 

Wait for the download to complete.


Once the download is complete, a screen will display some important information and instructions regarding the installation.

5. Follow the indications carefully in order to carry out a correct installation.
6. Select the desired option.




INFORMATION

By selecting the option Install Immediately, all the other downloads in progress will be suspended and the functions currently running will be closed.


7. Press: 
8. The software starts the installation of IDC6 Installer.
IDC6 Installer is a specific application that allows managing the download and update of IDC6.
9. Follow the instructions that appear on screen.

IDC6 Installer will start automatically at the end of the installation.
The list of updates available is displayed.


10. Press:




11. Press:



Wait for the update download and installation to finish.



12. Press: **Start IDC6**



The software is started and ready for use.

7 NEW CUSTOMER

The installation procedure below is reserved for new customers, who do not have any version of the diagnostic software.

The download and installation of IDC6 are managed by a specific application: IDC6 Installer.

INFORMATION

For the correct installation of the purchased environments, you must have the activation codes associated with them.

For further information, contact your retailer.

INFORMATION

Use of the software is regulated by specific licence contracts displayed during the activation and that must be read and accepted by the Customer. Likewise, the licence contract must be accepted by the Customer at each update by the licensor. The licence contract can be consulted at any time in the specific software section.

Proceed as follows:

1. Connect to the website: <http://go.texa.com/idc6/download>
2. The following screen is displayed.

Press: **Download IDC6 Installer**

IDC6 Quick Start Guide Lingua italiano

Grazie per aver scelto TEXA

Gentile Cliente,

Desideriamo ringraziarla per aver scelto il nostro software IDC6. La sua fiducia è per noi motivo di grande orgoglio e ci motiva a continuare a migliorare i nostri prodotti per soddisfare al meglio le sue esigenze. Siamo certi che IDC6 sarà uno strumento prezioso per le sue attività, offrendole le migliori soluzioni per la diagnosi e l'assistenza tecnica.


Questa guida la guiderà passo passo nell'installazione di IDC6 sul suo dispositivo.

1 Download di IDC6 Installer

IDC6 Installer offre un'installazione modulare di IDC6, permettendoti di selezionare e installare solo gli ambienti di cui hai bisogno, ottimizzando spazio e prestazioni del sistema.


Ogni ambiente è dotato di strumenti avanzati specifici per il settore, migliorando l'efficienza lavorativa.

Consente inoltre di mantenere gli ambienti aggiornati, con la possibilità di scegliere tra aggiornamenti manuali o automatici e di programmare gli orari di aggiornamento per minimizzare le interruzioni.



Scarica IDC6 Installer ↓

2 Inserimento codice di attivazione

Al termine dell'installazione di IDC6 Installer, sarà necessario inserire il codice di attivazione fornito dal rivenditore autorizzato cliccando sull'icona .

Questo codice consente al software di visualizzare e preparare l'installazione dell'ambiente a cui è collegato.

Dopo l'attivazione, l'installer consentirà di visualizzare eventuali altri ambienti disponibili senza dover inserire nuovi codici. Tuttavia, per attivare ulteriori ambienti, sarà necessario utilizzare il codice di attivazione specifico per ciascun ambiente richiesto.

Qualora non fossi in possesso del codice di attivazione, ti invitiamo a contattare il tuo rivenditore di fiducia per ricevere assistenza.

3 Download ambienti

IDC6 Installer ti permette di selezionare e installare solo gli ambienti di cui hai bisogno. Seleziona il tasto Installa per avviare il download e l'installazione dell'ambiente.

Quando sono disponibili nuove versioni, puoi scegliere di aggiornare manualmente gli ambienti oppure impostare aggiornamenti automatici per garantirti sempre le ultime novità senza intervento manuale.

È possibile inoltre programmare l'orario degli aggiornamenti, consentendo di pianificarli nei momenti più convenienti per il tuo lavoro, riducendo al minimo l'interruzione delle tue attività.

4 Attivazione del prodotto

Avvia IDC6 cliccando sul pulsante dedicato, situato in alto a sinistra nella barra superiore di IDC6 Installer.

Dopo l'avvio del launcher, seleziona l'ambiente che desideri utilizzare. Ti verrà richiesta l'attivazione della licenza.

Segui le istruzioni a schermo per completare il processo.

Manuali utente


Accedi ai manuali di IDC6 che ti guideranno nell'utilizzo ottimale del software, offrendoti istruzioni dettagliate su tutte le funzionalità, suggerimenti per la risoluzione dei problemi e approfondimenti sulle operazioni diagnostiche.

Scarica i manuali ↗

3. Press the icon IDC6 Installer that appears on the desktop.
4. Follow the instructions that appear on screen.


5. IDC6 Installer will start automatically at the end of the installation.
Connect the HASP key to the device on which you are carrying out the installation.

Press: 



6. Enter the activation code provided by your distributor.

Press: **Check**




INFORMATION

This operation is only required for the first environment you wish to install.


7. The software displays the environment that the entered code refers to.

Press: 



8. The software displays the languages available for the installation.


Press: 



Wait for the update download and installation to finish.


9. The environment is installed.

Press: **Start IDC6**



10. The software displays the desktop screen.

Click on the icon of the desired environment.



11. The software displays the environment activation screen.

The field related to the activation code is pre-filled with the code entered previously.

Press: **Activate**

First activation

You are trying to activate the software TEXA IDC6 TRUCK 2025.03.00

Activation Language
 English (en-GB)

Activation code [Paste](#) [Copy](#)

A B C D E F G H J 1 2 3

[Cancel](#) [Activate](#)

12. The SOFTWARE LICENSE AGREEMENT is displayed.

Scroll down to the end of the document.

Tick the boxes in the lower part of the screen.

Press: **I Accept**

TEXA IDC6 - License agreement

SOFTWARE USER LICENCE - TEXA IDC6

Please read carefully this user licence (hereinafter also referred to as "Licence") before using the Software.

DEFINITIONS:
 The terms subsequently indicated with a capital letter will have the following meaning, with the clarification that the terms defined in the singular are also intended to refer to the plural and vice versa.
 End Customer: the subject (natural or legal person) owner or possessor of the vehicle being diagnosed through the Diagnostic Tool.
 Third Party Content: any programs, information, databases, products supplied by Third Parties and made available through the Software, under the conditions indicated below and according to the terms and conditions applied by TEXA and/or by the Third Parties.
 Licensor or TEXA: the company TEXA S.p.A., with registered office in Italy, 31055 Montebelluna di Treviso (TV), Via P. Maggiorani n. 9, Tax Code/VAT 02413550266, owner of all rights relating to the Software.
 TEXA Services: the services provided by TEXA, purchased by the User and/or made available to the latter through the Software.
 Software: the TEXA IDC6 Software and any technical and IT content, TEXA databases, updates, supplement, service, including any additional software and firmware produced or developed by TEXA, all licensed for use under this Licence. The Software also includes Third Party Content that can be accessed through the Software, unless the latter is accompanied by specific conditions.
 Display Tool: the tool for visualisation, processing and communication of data produced by TEXA, or other suitable display tool, according to the specifications provided by TEXA, used by the User to manage interaction with the TEXA VCI and TEXA Services through the TEXA Software (e.g. tablet, PC).
 Diagnostic Tool: the vehicle diagnostic interface, consisting of a TEXA VCI and a Display Tool, through which the Software can be executed.
 Third Party: the subject (natural or legal person) other than the Licensor and the User.
 User: the subject (natural or legal person) to whom the Software used to provide the TEXA Services is licensed.
 TEXA VCI: the vehicle diagnostic interface manufactured by TEXA.
 TEXA AI: the various functions, developed by TEXA through the application of artificial intelligence, based on sources validated by TEXA, that help Users with the purpose of simplifying and summarising the search for information useful for the repair/maintenance/diagnosis. TEXA AI is available for Users after subscribing to the TEXA Services that enable its functions inside the Software, against payment of the related fee (as indicated in TEXA list prices and/or promotional literature).

1. SUBJECT OF THE LICENCE

1.1 The Licensor grants, in return for payment, the User, who accepts by pressing the consent/acceptance button ("point and click") through the graphical interface of the Software, the Licence to use the Software. This Licence is however deemed accepted by the user at the time of installation or use, in any way, of the Software.
 This Licence is a binding contract, with full legal effect between the Licensor and the User, for the licensing of the Software under the following conditions. This Licence is non-exclusive, non-transferable, except for the case expressly and specifically provided for by TEXA, limited to the territory of the Country indicated in art. 1.4, valid for the duration indicated in art. 2 and for the purposes referred to in art. 1.5 and 4; subject to the additional terms and conditions provided for in the Software License Agreement together with TEXA products and/or TEXA Services, the relevant terms and conditions of sale of the product or provision of the TEXA Service will also apply, in addition to those set out hereinafter in this case. There is a conflict between the provisions contained in the above-mentioned conditions of sale of product or provision of TEXA Services and other provisions of this Licence, the former shall prevail over the conflicting provisions contained in the Licence.
 1.2 The Licence relates to the single Software installed/connected with a specific Diagnostic Tool. The Software can also be used on different devices operating as a Display Tool belonging to the same user, but never simultaneously.
 1.3 The Software is accessible in the territory of the Country in which the Software was originally obtained, unless the Licensor expressly grants a more extensive territorial use. In any case, the Licensor has the right to limit or block, at any time, some particular functions or services of the Software in specific Countries, communicating such limitations to the User, who will have the burden of verifying the coverage and functions/services of the Software available in the Country in which it operates or intends to operate, without any liability of the Licensor in this regard.
 This Licence authorises the user to carry out the following activities:


I, the undersigned, declare I have read, understood and accepted the terms of this Licence.

I, the undersigned, expressly approve and accept, pursuant to the articles 1341 and 1342 of the Italian Civil Code, the provisions in the following articles: art. 1 (subject of the Licence), art. 2 (duration), art. 3 (Software property and prohibition of assignment), art. 4 (Software use and restrictions), art. 5 (expressed termination clause), art. 6 (warranty and responsibility), art. 7 (updates), art. 9 (indemnity clause), art. 11 (General provisions).

[I Do Not Accept](#) [I Accept](#)

13. The software displays the welcome screen for the initial configuration.

Press: **Start the configuration**



14. Follow the instructions that appear on screen until completing the configuration.

INFORMATION

IDC6 Installer *displays any other environment available for download at the next start-up or, alternatively, press: **Search for updates***

Each environment must be activated individually, by entering the related activation code manually.